

PreInsulatedPipe.com

Installation Procedures



1. Wrap the PVC cover around the joint to be covered.



2. Position the PVC cover in place, adjust for a good fit and tape the cover overlap securely.



3. Use a squeeze bottle or oil can to apply a bead of Ceel-Tight adhesive around both ends of the PVC cover and the overlap.



4. Wrap each end securely with two layers of tape. Smooth the overlap and tape it secure.



5. Take several turns of tape from one end of the joint to the opposite end. This will add support to the cover during the foaming process.



6. Drill two 1/4" holes in the cover, one near each end. These are for injecting the foam into the cover.